ASK NIBBLE



Ask Nibble of course!
Send your questions to Ask Nibble,
52 Domino Dr., Concord, MA 01742.

How can I print the Hi-Res screen on my ImageWriter printer?

This has been one of the most frequently asked questions in the last year, and although the answer cannot be given in just a paragraph or two, this information is so useful that I'll present the key pieces of information in this month's column.

Since many of you will want the information presented for an Appleotin program, and the rest of you will want in in ascernibly language. I'm granting both your wishes and doing it in both hazuges at once! Actually, some low-level operations are very child to do in BASIC, and so you really need some assembly language rottime. On the other hand, given an assembly language rottime to handle the bits on the screen, the main program to do the screen dump can be done in a very few lines of BASIC.

In theory, printing graphies on the ImageWirel (this same route all as works on the ImageWirel (this same route all as works on the ImageWirel I and Scribe) is very simple. You simply send the printer an initializing code, and thereafter every set bit in each screen byte causes a single pixel to print on your graphies image. This is identical to the way Hi-Res graphies is created on the screen, so everything should be easy.


Here the catche The Hi-Roberteer was the first seven bis in a beyt to pit divided by the pit of the seven bis in a beyt to pit divided, but the pit of the

Figure 1 aboves the upper left-hand corner of the Hi-Res screen Figure 1 aboves the upper left-hand corner of the Hi-Res screen Figure 1 aboves the upper left-hand corner of health per per gram first craws a frame around the personn (Listing 3). The program first craws a frame around the personn findle of the screen. The diagram shows an enlarged view of both the screen and printer pixels, and shows the data beytes for each. For the screen, the first group of eight bytes are STF, 507, 501, 519, 531, 561, 531 and 501. Each byte represents seven horizontal pixels on the screen.

Roger Wagner is the president of Roger Wagner Publishing, Inc., the publisher of MouseWrite and the Merlin Assembler, and the author of Assembly Lines: The Book and Apple IIGS. Assembly Language for Beginners. The program is compatible with both Pro-DOS and DOS 3.3. To print this, the program must send out seven new bytes, each of which contains a vertical group of eight pixels. As seen in Figure 1, the bytes sent to the printer are not the same as the bytes in screen memory (\$2000 to \$38FE).

memory (2,2000 to 25eFF).

The approach I have taken is to write an assembly language routine that takes a given X, Y screen coordinate and returns seen bytes
containing that pixel within a block that is seven pixels wide and
eight pixels high. This is convenient for a number of reasons. First,
it is a logical chunk of memory to process — the lowest common
denominator of the screen and the printer, as it were. Also, b hya-



R01100001 - 131 R11000001 - 161 Figure 1: Converting Screen Pixels to Printer Dots

To start, Listing 1 shows you the screen processing routine. I'll summarize the main points of the routine. The routine is called with the statement CALL AD, X, Y, AS, where AD is the routine.

tine's address, x, y is

ing the routine pro-

cess only a part of

memory, some limit-

ed degree of partial

screen printing is

available, allowing

you to print just part

of a Hi-Res screen if

you wish. Last of all,

the 7 x 8 pattern cor-

responds to the most

common Hi-Res char-

acter generator pat-

tern, which means

that the screen chunks

match single charac-

ters put on the screen

by most Hi-Res print-

printed perfectly

ing routines.

the starting point of the screen block, and Af is the string to return. The START section checks to make sure we're not in BASIC'S immediate mode. This is because the program uses part of the input buffer (528-028) as the work area to build the bytes to send to the printer. XPOSN and TESTX then evaluate the ApplicsO trainble for the horizontal position, and tests to make sure X is not greater than 273, since we'll be reading from there to X=279. YPOSN does a similar function for the Y position.

The processing routine itself will set up seven bytes in memory, all set to zero, and then use the ROB instruction to move bits into each byte of the output group as the screen bytes are scanned. Locating the byte in memory that corresponds to a given screen position can be tricky, to well use the built-in Applecant routine FPOSN. SETUP clears the seven bytes in our buffer to zero; then LO-CATE uses HOSOs to find the base address of the upper-fiel corner

SELUP clears the seven bytes in our outlier to zero; then LUCATE uses HPOSN to find the base address of the upper-left corner of the screen memory byte group. This "home" value is saved in XVAL and XVAL, so that we can return there after each vertical

row of bits is scanned.

GBTCOL is the beginning of the real working part of the routine, and sets a MASK value to SOI, corresponding to our examination of the first bit of the screen byte in the first row. TOP initializes the pointer GBASL to use indirect addressing as we scan the bytes. We'll also set up a counter to tell us when we've scanned the eight rows of screen bytes.

OFTBYTE gets the hyte from screen memory; by ANDing this with MASK, we can tell whether the first pixel (tit 6) is on. If it is, the Carry bit is set in SET and pushed into the first byte in the buffer. NATBYTE uses the II-Hes routine INCRY, which automatically adjusts GBASI, to point to the next line down for each pass through the boy. On each successive loop through GETBYTE, successive bits are pushed into this first byte, until we've pushed algely his INXTOCOL increments he X-register so successive the history of the control of the property of the p

SENDSTR then wands the eight bytes back to Appleant as a stringvariable. One interesting titidab there, as revarial of othese wascusally read the text of program explanations, is that this technique is different from the general purpose string-passing most of the program of the program of the program of the proposed and the program of the program of the proting of the program of the protes and the program of the protes and the program of the protes and the protest and the protes and the protes and the protest and the pro

The BASIC program is in Listing 3. The program begins by loading or bitmap promise at SZAN. Normally, I would have loaders SXO as a location for this, but in a moment we're point to need to more routine that is used to send the bytes to the printer, and the two together just won't fit into the available to bytes to the printer, and the two together just won't fit into the available routine part of the really in the product of the imput before, but more on the identifies later of the product o

Graphics printing on the ImageWriter and computible printers is very easy, at least in regards to setting himse yu. After the usual PR#1 to turn on the printer, we have to put the interface card into the "transparent mode means the printer card won't be looking for a Control-I in the data stream, and likewise, won't ad line foest to carriage reart mode means the printer card won't be looking for a Control-I in the data stream, and likewise, won't ad line foest to carriage reart bytes. This is most some card with the printer card won't be adding linefeed, we will have to do this our-selved united to the printer card won't be adding linefeeds, we will have to do this our-selved united to printout.

Escape n Escape T16 sets the character pitch and linefeed distance for a properly proportioned picture. You can experiment with other values and pitch commands to get smaller, denser pictures or larger images as you desire.

The actual graphics printing is initiated by telling the printer how many graphic bytes you are sending. The command is Escape G anum, where man is the number of bytes (i.e., groups of eight vertical pixels) you're sending. In our case, we're sending 280 bytes for the Hi-Res screen. Next, a nested loop scans positions 0 to 23 vertically. The actual Y coordinate is determined by multiplying the Y value by 8 (8 bytes per block). I could have used FOR Y = 0 TO 19 4 STEP 8, but I chose this form to show the correspondence to the positions on the text screen, in case you want to use this routine with a Hi-Res character generator.

The X loop likewise counts from 0 to 39, which is multiplied by 7 to get the true X coordinate. The call to the bitmap routine then returns the seven bytes to send to the printer.

The only catch now is printing the full range of data bytes to the printer. If you've sever experimented with this, you've found that Applessoft automatically sets the high bit on everything you try to print. If your program says PRINT CHRS/00, the printine actually receives CHRS/00+128. Fortunately, it is easy to create an alternate PRINT routine to the usual Applesoft command. Listing 4 is a routine that will print any string to the printer without conversion.

ImageWriter is very easy, at least in regards to setting things up.

Graphics printing on the

The routine is actually very simple. It just sends the characters in the string you specify directly to COUT (\$FDED = "Character Output"), bypassing the Applesoft routines entirely.

Final notes: One of the big problems with assembly language rouse is the problem of where to put them in memory and and not to fit several of them at once in a given area. These runtimes have been written to be completely position-independent, so they can be used at any location you with. That is to say, if you received he trial Size Toolson offered for fire in this cloums several times in the past, you can use the Workbeech program without having to worry at all about finding a memory location. The vyinks may be about the properties of the properties without having to worry at all about finding a memory location. The vyinks we have the properties of t

I hope this has lelped you get the general idea behind printing graphics on your printer. If you do not have an ImageWriter printer or compatible, vij looking thirough the reference manual that came with your printer. Chances are that except for minor differences in the printer initialization sequence, you'll be able to use the general principles provided here with very little modification. Have fun!

ENTERING THE PROGRAMS

If you have an assembler, use the source code from Listing 1 and save the object code as ROTATE. If you don't have an assembler, use the hex code from Listing 2 and save it with the command

BSAVE ROTATE, A\$8000, L\$AA

Enter the Applesoft program in Listing 3 and save it with the command


SAVE IW. PRINT. DEMO

If you have an assembler, use the source code from Listing 4 and save the object code as ALT.PRINT. If you don't have an assembler, use the hex code from Listing 5 and save it with the command

BSAVE ALT. PRINT, A\$8000, \$2C

P.S. If you haven't gotten your Trial Size Toolbox, you can still

P.S. If you naven't gotten your Trial Size Toolbox, you can sun receive one for free by writing to me at Roger Wagner Publishing. Inc., 1050 Pioneer Way, Suite "P", El Cajon, CA 92020, and mentioning that you're an Ask Nibble reader!



```
186
                                                                             AE
                                                                                    78
                                                                                         HPLOT 0.0 TO 279.0 TO 279.191 TO 0.191 TO 0
    SET
INJECT1
             SEC
                   DUFFER X
                              INJECT SET BIT IN BYTE Y OF BUCCOD
                                                                                           a
100
                               . AL WAYS
                                                                                    90
                                                                                         REM PRINTER DUMP
118 CLR
111 INJ
112
                                                                             49
                                                                                    90
                                                                                          PRINT
                                                                                           PRINT CHRS (4);"PR#1"
PRINT CHRS (9);"K"; CHRS (9);"Z"; REM NO
    INJECTZ
             ROR
                   BUFFER.X
                              : INJECT CLR BIT IN BYTE X OF BUFFFR
                                                                             92
                                                                                    100
                                                                                           LF W/ CR: TRANSP MODE
113 NKTBYTE
                   INCRY
                              ---
                                                                                    110
                                                                                           PRINT CHR$ (27); "n"; CHR$ (27); "T16"
                                                                             4F
                   CETRYTE
                              : GET NEXT PIXEL DOWN
                                                                             AG
                                                                                    126
                                                                                           FOR Y = 0 TO 23
116
                                                                                           PRINT CHR$ (27); "GØ280";
FOR X = Ø TO 39
                                                                             94
                                                                                    130
117 NKTCOL
             INV
                               NEXT BYTE IN SUFFER
                                                                             64
                                                                                    140
             ASL
119
             no:
                                RE-PONN CURSOR AND GET NEXT COL
                                                                             07
                                                                                    150
                                                                                           CALL 672 X + 7 Y + R AS: REN GET SCREEN R
    SENDSTR
             100
                                                                                          VTES
122
             JSR
                   PTRGET
                                FIND VARIABLE OR MAKE IT
MAKE SURE IT'S A STRING
A.Y = DESCRIPTOR TO STRING
                                                                             49
                                                                                    160
                                                                                           CALL 848.AS: REM TRANSPARENT PRINT
                                                                                           NEXT X: PRINT CHRS (10)
                                                                             6D
                                                                                    170
                   FORPNT
FORPNT
                                                                                           NEYT Y
                                                                             ac
                                                                                    188
                                                                             25
                                                                                    198
                                                                                           PRINT CHR$ (4); "PR#0"
                   #507
STRSPA
                                LEN OF STRING (7 CHARS)
SET UP SPACE IN MEMORY
127
                   #<BUFFER
#>BUFFER
WOVSTR
PUTNEW
                                SET UP SPACE IN MEMORY
LOW RYTE OF DATA
HIGH BYTE OF DATA
MOVE DATA TO MEMORY
MOVE DESCRIPTOR TO TEMP
                                                                             TOTAL - 0F31
             LOK
130
             LDY
                                                                             END OF LISTING 9
135 DONE
             RTS
137 CHKSUN
            ***
                              CHECKSIN - 48 (ONLY FOR OTHER ASSESSIONS
                                                                             LISTING 4: ALT.PRINT Source Code
END OF LISTING 1
                                                                              1 = 2 = ALT.PRINT Source :

3 = by Roger Magner 

4 = Copyright(c) 1988 

5 = WicroSPMRC, Inc. 

5 = Concord, MA 01742 

7 = Werlin 8/16
                                                                                - ALT PRINT Source Code
LISTING 2: ROTATE
Start: 8000
                               Length: AA
5F 8888 28 86 F3 28 B7 88 C9 20
A3 8008: D0 03 20 BE DE 20 67 DD
68 8010: 20 52 E7 A5 50 85 3E A5
                                                                             10
                                                                                               SFDED
S9D
                                                                                                          : CHARACTER OUTPUT ROUTINE
: TEMP LOCATION FOR STRS LENGTH
: (NORMALLY FAC)
                                                                                LEN
E3 8018
           51
               85
                    3F
                        CO
                            01 D0
                                    OR AS
16 8020:3E C9 12 90 05 A2 35 4C
                                                                                               $55FD
$55
85 8028 12 D4 20 4C E7 86 41 E0
                                                                                THOSE
                                                                                                           : $56.5F
: CHECK FOR DIRECT MODE
20
    8030 R9
               98 85 A2
                            35 4C 12 D4
E1 8038 A2 06 A9 00 90 80 02 CA
49 8040 10 FA A6 3E A4 3F A5 41
9A 8048 20 11 F4 A5 26 85 3E A5
OE 8050:27 85 3F A5 E5 84 41 A9
                                                                             22 START
23
                                                                                         JSR
JSR
CWP
                                                                                               ILDIR
CHRGOT
                                                                                                          : MAKE SURE WE'RE NOT IN IMMED MODE
    8058:01
               85 3C A2 00 A4 E5 A9
                                                                                                          : CHECK FOR COMMA
                                                                                               NAME
BO 8060:08 85 3D A5 3F 85 26 A5
                                                                                                          NO COMMA
AE 8068:3F 85 27 A4 41 B1 26 25
                                                                                         158
                                                                                               CHECOM
D1
    8070:3C FØ Ø6 38 7E
                                80 02 D0
                                                                               NARE
                                                                                                          : EVALUATE STRING EXPRESSION
: WAKE SURE IT'S A STRING AND
: SET UP POINTERS
: (A=LEN, INDEX=LOC)
    8078:04 18 7E 80 02 20 04 F5
                                                                             **
                                                                                         100
                                                                                               COCCED
    8080 C6 3D D0 F9 F8 06 3C 10
   8088:D6 20 BE DE 20 E3 DF 20
                                                                             32
33 CHECK
34
9E 8090:6C DD 85 85 84 86 A9 07
                                                                                         DINE
LOX
JWP
                                                                                                          : CHECK FOR LEN = 0
DB 8098:20 DD E3 A2 80 A0 02 20
                                                                                               PRINT
FFERR
99 80A0:E2 E5 20 2A E4 20 9A DA
26 80A8:60 4B
                                                                             35 ERR
                                                                                                          : ILL QTY ERR
                                                                                         STA
                                                                             38 PRINT
                                                                                                            START AT BEG. OF STRING
GET CHAR OF NAME STRING
PRINT IT
TOTAL: AE58
                                                                                               #500
                                                                             48 LOCE
                                                                                         JSR
INY
                                                                                               (INDEX).Y
END OF LISTING 2
                                                                                                          : DONE YET?
                                                                                         BCC
                                                                                               1000
                                                                                         RTS
                                                                                                          ALL DONE
                                                                             48 CHASIN
                                                                                         CHI
                                                                                                          CHECKSUM = 60 (OMIT FOR OTHER ASSEMBLERS)
LISTING 3: IW.PRINT.DEMO
                                                                             END OF LISTING 4
CR
           REM
47
           REM
                 · IW.PRINT.DEMO
                                                                             LISTING 5: ALT.PRINT
47
           DEM
                 . BY ROGER WAGNER
3F
                 · COPYRIGHT(C) 1988
           REM
                                                                             Start: 8000
                                                                                                           Length: 2C
3P
                 MICROSPARC, INC.
           REM
RF
           REM
                                                                             5E 8000:20 06 E3 20 B7 00 C9 2C
D7 8008:D0 03 20 BE DE 20 78 DD
BF
           REM
99
       10
            PRINT
                     CHR$ (4): "BLOAD ROTATE, A$2A0": REM
                                                                             79 8010:20 FD E5 C9 00 D0 05 A2
             672 DEC
                                                                             AE 8018:35 4C 12 D4 85 9D A0 00
AB
       20
            PRINT CHR$ (4); "BLOAD ALT PRINT A$350";
                                                                             23 8020:B1 5E 20 ED FD C8 C4 9D
             REM 848 DEC
                                                                             B6 8028:90 F6 60 6B
       30
            REM DRAW PICTURE
01
       40
            HGR
                                                                             TOTAL - RARI
44
       50
            HCOLOR- 3
ED
            HPLOT 0.0 TO 100,100
                                                                             END OF LISTING 5
```